

Workflow 2: Setting the Annotation Scale in the Model Properties

1. From the MicroStation Primary toolbar, select the Models icon.



Figure 5-7: Primary Tools

2. From the Models dialog box, select Model Properties.




Figure 5-8: Models Dialog

3. Select the Edit Model Properties Icon.




Figure 5-9: Model Properties

4. You can rename the model, give a new description and select the annotation scale from the dialog above. In the example above, the annotation scale has been set to 1"=100'. Once the model properties have been set, select OK.