



## Workflow 1: Attaching a level library

1. *Open the Level Manager by selecting the icon in the Primary Tools tool bar, or by selecting Settings>Level>Manager.*



Figure 9-1: Accessing Level Manager




Figure 9-2: Accessing Level Manager

2. *Notice the dialog that is activated has only one level shown, Default. These are also no level filters available.*




Figure 9-3: Level Manager

3. *Select Levels>Library>Attach.*




Figure 9-4: Attaching DGN Library

4. *Browse to the file FLH\_Combined.dgnlib, select OK. The Library Files are located in the: Standards\IV8\_RESOURCE\IX\_30\Standards\Library\_Files\ directory.*




Figure 9-5: Level Manager with DGN Library Attached